

This Quick Start Guide is intended for experienced installing technicians. It is a basic reference to ensure all connections are properly made.

1.0 Introduction

A key component of a physical security electronic access control system, a proximity card reader is based on RFID technology. In operation it is capable of reading data stored on a proximity credential via radio frequency and without physical contact, and then passing the data obtained to the physical access control system. Access control systems typically manage and record the movement of individuals through a protected area, such as a locked door.

2.0 Mounting Provisions

Each reader may be installed either indoors or outdoors. Use supplied #6 mounting screws, or equivalent security screws, for installation.

Mullion* = Install single-piece potted reader

Single-gang wall box* = single-piece potted reader + back plate

*Plastic or metal

3.0 Reader Wiring

Wiegand	
Conductor	Function
Red	DC (5-16 VDC)
Black	Ground
Green	Data 0
White	Data 1
Brown	Red LED ^a
Orange	Green LED ^b
Yellow	Card Present
Blue	Beeper
Violet	fleaPower
Drain	Shield Ground

Magstripe	
Conductor	Function
Red	DC (5-16 VDC)
Black	Ground
Green	Clock
White	Data
Brown	Red LED
Orange	Green LED
Yellow	Card Present
Blue	Beeper
Violet	fleaPower
Drain	Shield Ground

WIRING NOTES:

^a**Single Line LED:** This is the standard operating mode and does not make use of the Orange conductor. The LED is Red when the reader is idle and flashes when a card is presented. The LED turns Green when the Brown Conductor is pulled low by the access control panel.

^b**Dual Line LED:** This mode makes use of both the Brown and Orange conductors. The Brown conductor controls the Red LED and the Orange conductor controls the Green LED. LED states are determined by the access control system option and capability.

Unused conductors should be trimmed, isolated and taped back to prevent unintended current flows. Apply positive voltage only to the Red DC Conductor.

4.0 Cable Requirements

22 AWG minimum (18 AWG recommended > 250' runs) , multi-conductor stranded with an overall foil shield supporting the six conductors comprising the physical layer of the Wiegand interface (power, ground, data 0, data 1, and/or beeper and LED). Contact Aiphone Corporation for specific requirements. Per SIA's Wiegand specification, maximum cable length is 500 feet (152 m).

5.0 Output Formats

Wiegand (industry standard 26-bit Wiegand and custom Wiegand formats).

6.0 Grounding

Shield (drain) continuity must run from the reader to the access panel. Shield (drain) and reader ground must be tied together at the access panel and connect to an earth ground at one point.

7.0 Power

Reader may be powered by the access panel. A linear power supply is recommended for best operation.

8.0 Voltage and Current

Voltage: 5 to 16 VDC

Current Draw: 30mA typical, 75mA peak

9.0 fleaPower™ Control Line

To reduce the average current required by the reader, pull the purple conductor low.

10.0 Connection

Connection must be done in accordance with NFPA 70. Do not connect to a receptacle controlled by a switch. Connect to a power limited DC voltage source.

11.0 Troubleshooting

1. When the reader is first powered on it will beep 4-times, and the LED will shine red.
2. Presenting a supported access credential will result in the reader beeping and the LED flashing once.

NOTE: The access panel controls LED functionality, such as switching the LED to green.

See additional troubleshooting information on reverse.

AC-PROX-1G Proximity Card Reader

125- kHz

If the reader does not recognize the card or tag (no beep, no LED flash) or exhibits short read range, please see the table below for possible causes and solutions.

Possible Cause	Corrective Action
Incorrect cabling	Verify gauge, connections and cabling length
Not enough power	12 VDC recommended, 5 VDC at reader is minimum
Incorrect card used	Verify if card technology is supported
Reader/access panel not properly grounded	Earth ground needed—verify shield and reader ground are tied at access panel and connect to ground at one point
Supply generating interference	Linear power supply recommended, verify switching power supply before use

Should any of the corrective actions mentioned above not improve performance, disconnect the reader from the access panel and power it with a separate power supply or 9VDC battery, and re-test card functionality. By powering the readers separately, most variables that may lead to reduced performance can be eliminated. Should the problem persist, please contact Aiphone Corporation directly.

Operating Temperature: -31° F to +150° F (-35° C to +66° C)

Operating Humidity: 0% to 90% Relative Humidity

IP Rating: IP67-rated for outdoor use

Access Control Performance Levels Conforming to UL STD 294:

Destructive Attack	Line Security	Endurance	Standby Power
Level II	Level I	Level IV	Level I

Grade Classification Certified to CAN/ULC STD 60839-11-1:

Risk Level	Application	Skill/ Knowledge of Attackers	Typical Examples
Grade 2	Grade 2	Grade 2	Grade 2

The AC-PROX-1G carries the following certifications:



FCC Compliance Statement: This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by Aiphone Corporation could void the user's authority to operate the equipment.

Product can be used without license conditions or restrictions in all European Union countries, including Austria, Belgium, Bulgaria, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Poland, Portugal, Romania, Slovakia, Spain, Sweden, United Kingdom, as well as other non-EU countries, including Iceland, Norway, and Switzerland.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme à Industrie Canada exempts de licence standard RSS (s). Le fonctionnement est soumis aux deux conditions suivantes : (1) ce dispositif ne peut pas provoquer d'interférences et (2) ce dispositif doit accepter toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement du dispositif.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.