

Plug-In Transformers



Specification Chart:

Model #	Output	Amp	UL Listed	Dimensions (Fig. 1)			
				Α	В	С	D
TP1220	12VAC/20VA	1.7	✓	1.884" (47.85mm)	2.5" (63.5mm)	3" (76.2mm)	3.35" (85.09mm)
TP1620	16.5VAC/20VA	1.2	✓	1.884" (47.85mm)	2.5" (63.5mm)	3" (76.2mm)	3.35" (85.09mm)
TP1640	16.5VAC/40VA	2.4	✓	2.353" (59.77mm)	2.658" (67.51mm)	3.186" (80.9mm)	3.562" (90.47mm)
TP1650	16.5VAC/50VA	3.0	✓	2.353" (59.77mm)	2.658" (67.51mm)	3.186" (80.9mm)	3.562" (90.47mm)
TP2420	24VAC/20VA	8.0	✓	1.884" (47.85mm)	2.5" (63.5mm)	3" (76.2mm)	3.35" (85.09mm)
TP2440	24VAC/40VA	1.67	✓	2.353" (59.77mm)	2.658" (67.51mm)	3.186" (80.9mm)	3.562" (90.47mm)
TP2450	24VAC/50VA	2.0	✓	2.353" (59.77mm)	2.658" (67.51mm)	3.186" (80.9mm)	3.562" (90.47mm)

Installation Instructions:

- 1. Connect wires to plug-in transformer.
- 2. Measure output voltage before connecting devices. This helps avoiding potential damage.
- 3. Plug in the transformer to an outlet and secure transformer with screw provided.

WARNING: This installation should be made by qualified service personnel and should conform to the National Electrical Code and all local codes.

Plug-in Transformer Diagram

Fig. 1





