

# SLCE-127 ADDRESSABLE LOOP EXPANDER





Product includes a 5 year warranty

### **Features**

- · No special wiring
- Class A or B capable
- Mounts with included stacker bracket
- May mount in panel, accessory cabinet, or PSN-1000/E Power Supply
- Alarm Current 400 mA0°C–49°C (32°F–120°F) 10%-93% @30°C(86°F) non-condensing humidity ambient operating temperature
- Maximum 1 SLCE-127 for PFC-6200
- Maximum 7 SLCE-127 for PFC-6800
- Size (W x H x D) is 4" x 6" x 1-5/8"

### Electrical Specs

- 60 mA alarm current
- 60 mA standby current


## Description

The Signaling Line Circuit Expander (SLCE-127) allows for an additional loop for the PFC-6200 and up to seven additional loops for PFC-6800 fire alarm control panels. Each loop adds 127 addressable sensors or modules in any combination. The SLCE-127 may be configured for Class A or Class B wiring without the need for additional modules. The SLCE-127 communicates with the control panel via the Potter P-Link communication bus. The loop adder is mounted in either the control panel cabinet, the intelligent power supply/P-Link repeater, the PSN-1000E, AE-8 or the AE-14 expander cabinet. Each card is mounted to the exclusive Stacker Bracket for secure and accessible mounting.


## Installation

The SLCE-127 is connected to the PFC-6000 series panels using a four wire RS-485 connection. This connection is power limited and supervised. The SLCE-127 can be installed in the AE-8 Accessory Enclosure, AE-14 Accessory Enclosure or inside the large PFC series enclosure using the supplied bracket.

# **SLCE-127 Class B P-LINK Wiring Example**



# **SLCE-127 Class A P-LINK Wiring Example**



DWG • 516-933-4900 • dwgdistribution.com